



Core - CRE35 Harbour

©2020 C.F.Stinson, LLC. All rights reserved.

Content	Vinyl Surface with Polyester Backing
Finish	Advanced Soil and Stain Resistant Top Coat
Cleaning Code	(W) Clean with water-based foam or water-based cleaners only. Do not use solvents. We recommend using a professional cleaning service. Bleach solutions of up to 10% may be used for more difficult stains.

Visit cfstinson.com for complete specifications.

Maintenance / General Recommendations

Clean and maintain your furniture regularly. Cleaning frequency depends on use. We recommend using a professional furniture cleaning service.

Always test cleaning solutions and methods in an inconspicuous area of the furniture before proceeding. Treat spills and stains promptly. The longer the stain remains, the more difficult it will be to remove. Clean spots or stains from the edge of the stain working toward the center.

For regular cleaning and maintenance, remove excess soil with a damp, non-abrasive cloth. Use a solution of mild liquid soap and water. Rinse with clean water and dry.

Stain Treatment / Disinfection

For stubborn stains or heavy soiling use a straight application of concentrated cleaners such as Formula 409® or Fantastik®. Wipe with clean, nonabrasive cloth, rinse with water and dry.

For more difficult stains or to disinfect, use a mixture of no more than 10% bleach and 90% water. **Always** rinse with clean water and dry. **Never** use full strength bleach to clean this material or any other coated fabric.

For the most difficult stains like ink, use a clean, non-abrasive cloth saturated with household rubbing alcohol (91% isopropyl alcohol) and rub the stain in circles. Pat dry with a clean, dry cloth. Rinse thoroughly with water and pat dry again.

We do not recommend the use of hard surface cleaners; however, the following cleaners / disinfectants have been tested for use on this material, diluted per manufacturer's instructions:

3M™ C. diff Solution Tablets	3M™ HB Quat Disinfectant Cleaner
3M™ Surface Disinfectant Cleaning Wipes	Accel® INTERvention™ RTU
Accel® INTERvention™ Wipes	Agar™ Powerquat
Alpha HP® Multi-Surface Disinfectant	Asepticare® TB+ II
Avert® Sporicidal Disinfectant Cleaner	Avert® Sporicidal Disinfectant Cleaner Wipes
Avistat-D™	Barbicide® Wipes
Betco® Quat-Stat™ 5	BirexSE®
Birex® Disinfectant Wipes	Bleach-Rite® Disinfecting Spray
Brulin® Maxima 256	CaviCide1™
CaviCide™	CaviWipes1™
CaviWipes™	CaviWipes™ AF
Citrace®	Clean On The Go Super HDQ®L 10
Clorox Healthcare® Bleach Germicidal Cleaner	Clorox Healthcare® Bleach Germicidal Wipes
Clorox Healthcare® Fuzion™ Cleaner Disinfectant	Clorox Healthcare® Hydrogen Peroxide Cleaner Disinfectant
Clorox Healthcare® Hydrogen Peroxide Cleaner Disinfectant Wipes	Clorox Healthcare® VersaSure® Cleaner Disinfectant Wipes
Clorox® Clean-Up® Cleaner + Bleach	Clorox® Total 360® Disinfectant
Crew® Bathroom Cleaner and Scale Remover	DisCide® Ultra
DisCide® Ultra Spray	DisCide® Ultra Towelettes
Ecolab® 14 Plus Antibacterial All Purpose Cleaner	Ecolab® Neutral Disinfectant Cleaner
Ecolab® Oasis® 146 Multi-Quat Sanitizer	Ecolab® Oasis® 499 HBV Disinfectant
Emerel® Multi-Surface Crème Cleanser	ERC Performance Wipes

EZ-KILL® Wipes	FaciliPro™ Carpet and Upholstery 3 in 1 Cleaner
Fade-A-Dyne II®	Fantastik®
Formula 409®	Glance® HC Glass and Multi-Surface Cleaner
HaloMist™ All-Purpose Disinfectant	Hepastat 256™
HyperFect 256	Isopropyl Alcohol
KAY-5® Sanitizer/Cleaner	KayQuat® II
KAY® SolidSense™ Sanitizer	Lysol® Foaming Disinfectant Cleaner
Lysol® Spray Disinfectant	MaxiSpray® Plus
McKesson Disposable Germicidal Surface Wipes	McKesson Pro-Tech RTU
Micro-Chem Plus™ Disinfectant Detergent	Micro-Kill™ Bleach Germicidal Wipes
Opti-Cide3® Surface Wipes	OPTIM® 1 Wipes
Optim™ 33 TB Disinfectant	Oxivir® 1 RTU
Oxivir® 1 Wipes	Oxivir® Five 16 Concentrate
Oxivir® Plus	Oxivir® TB
OxyCide™ Daily Disinfectant Cleaner	PCS 1000 Oxidizing Disinfectant Wipes
Percept™ Concentrated General Virucide Disinfectant Cleaner	PortionPac® Germicidal Cleaner
Precise® QTB Hospital Cleaner Disinfectant	Prochem® Oxy Plus
PURELL® Healthcare Surface Disinfectant	PURELL® Professional Surface Disinfectant
QSR Glass and Multi-Surface Cleaner	Sani Professional® Cleaning + Degreasing Multi-Surface Wipes
Sani-Cloth® AF3 Germicidal Disposable Wipe	Sani-Cloth® Bleach Germicidal Disposable Wipe
Sani-Cloth® HB Germicidal Disposable Wipe	Sani-Cloth® Plus Germicidal Disposable Cloth
Sani-Cloth® Prime Germicidal Disposable Wipe	Sani-Prime® Germicidal Spray
SaniZide Plus®	Shockwave™ RTU
STERI-7 XTRA Wipes	Steriplex® SD
Stride® Citrus Neutral Cleaner	Stryker SideKick™ Disinfecting Wipes
Super Sani-Cloth® Germicidal Disposable Wipe	TB-Cide Quat®
Vert-2-Go ED	Vert-2-Go Oxy
Virex® 128	Virex® II 256
Virex® Plus	Virex® TB
Virox® 5	Virox® Accel TB Wipes
Virox® PREempt™ RTU	Virox® Rescue®
Wex-Cide 128	

Marks are the property of their respective owners. No affiliation or endorsement is implied.

If these cleaners / disinfectants are used, the material **must** be rinsed with clean water and dried with a clean cloth following application. Failure to rinse thoroughly with clean water and to pat dry may lead to cleaner build up and cause surface deterioration (cracking, blisters, peeling, discoloration, etc.).

Do **not** use cleaners marked "for hard non-porous surfaces only" unless indicated above. Such use may cause surface deterioration (cracking, blisters, peeling, discoloration, etc.).

Caution:

- Indiscriminate use of strong cleaning chemicals can severely damage or discolor this material.
- Never apply full strength bleach to this material.
- Avoid cleaners containing abrasives.
- Do not use heat to clean this material. Hot water, hot water extraction, or steam cleaning is not recommended.
- Do not saturate material or let cleaning agents pool in seams.
- Several light applications of a cleaning agent are less harmful than a single concentrated application.
- Certain apparel dyes, including indigo dyes commonly used in denim jeans, may migrate on to the surface of the material and become visible on lighter colors. This phenomenon is increased by humidity and temperature and may be irreversible.
- Certain inks, including ball point ink can create permanent stains.
- If stain persists despite suggested cleaning methods, stain has probably set and may be permanent.
- Some solvents are highly flammable. Exercise proper care when cleaning with solvents and solvent cleaners. Read and follow manufacturer's directions on labels.

The information published in this Care Guide refers to performance of this product in specific tests conducted under laboratory conditions. Results may vary under actual conditions.

The information published in this Care Guide is not a guarantee and does not relieve the user from the responsibility of proper and safe use of the product and all cleaning agents. The use of certain agents can be harmful to the surface appearance and lifespan of the material. C.F. Stinson, LLC, its agents, representatives and assigns assume no responsibility resulting from the use of such cleaning agents on the material.

Under no circumstances shall C.F. Stinson, LLC be liable for any incidental, consequential, or other damage resulting from the negligence, misuse, mishandling, or exposure of any chemicals used in connection with maintenance and cleaning. Information relating to chemicals/cleaning agents, environmental use and human exposure should be reviewed with the appropriate suppliers. All label instructions on their use and precautions should be followed.

Stinson®

C.F. Stinson, LLC
2849 Product Drive
Rochester Hills, MI 48309

P 800 841 6279
F 248 299 3884

cfstinson.com