




Black




Dark Grey



Light Grey



Navy Blue



Bright Blue

## Content

Vinyl with a jersey knit backing

## Finish

Proprietary anti-slip technology

## Cleaning Code - W

Water-based cleaning

Frixion withstands hospital grade cleaners and disinfectants, ensuring a safe and hygienic working environment for healthcare workers and patients.

## Important notes

- For cleaners and disinfectants not listed, please contact us for more information. We are continually testing and adding new cleaners and disinfectants to our approved list.
- Read and follow the safety precautions and use directions on the cleaners/disinfectants labels.
- Cleaners/disinfectants should be used at the manufacturer recommended dilutions and never in concentrated form.
- After each application, disinfectants must be wiped off with clean water and dried with a clean towel to remove any chemical residue that could discolour or degrade the material surface.

## Cautions

- If you desire to use other cleaning solutions or methods, carefully test it on a small, inconspicuous area to ensure compatibility. Never use harsh solvents which may damage the upholstery.
- Cleaning products may be harmful/irritating to your skin, eyes, etc. Wear appropriate Personal Protective Equipment (PPE) to preclude exposure to infectious agents or chemicals.

It's essential to clean and maintain your seating products regularly in healthcare environment. Follow the [guideline](#) from the Centers for Disease Control and Prevention for Disinfection and Sterilization in Healthcare Facilities.

## Cleaning instructions

Remove spills and stains promptly with a soft damp cloth. Ensure the area is clean by wiping the surface with one of the RTU (ready to use) cleaning agents.

For light soiling, a solution of 10% mild soap with warm water will remove most soiling.

For more difficult stains, bleach solutions of up to 10% (containing sodium hypochlorite diluted 1:10) may be used.

For disinfection, wipe the surface again with RTU wipes. Allow the surface to air dry for the recommended dwell time (1-3 minutes – refer to the manufacturer's instructions).

As a best practice, regardless of the disinfectant chemistry is used, wipe the surface with a damp cloth and mild soap, followed by a final wipe with a water-dampened cloth.

The commonly used Hydrogen Peroxide and Quaternary Disinfectant Cleaners, such as the following products on the EPA list, have been tested and approved on Frixion:

- PREempt™ Disinfectant Wipes
- Oxivir® Tb Wipes
- Oxivir® Tb Spray
- Oxivir® Plus Disinfectant Cleaner Concentrate
- Clorox Healthcare® Hydrogen Peroxide Cleaner Disinfectant Wipes
- Clorox Healthcare® Bleach Germicidal Disinfectant Wipes
- PDI Healthcare Sani-Cloth® Bleach Germicidal Disposable Wipes
- PDI Healthcare Super Sani-Cloth® Bleach Germicidal Disposable Wipes
- Virex® II 256 Disinfectant Cleaner
- 3M™ Disinfectant Cleaner RCT Concentrate 40